

User Guide

To elevate your drinking experience.



1
To activate the device, press any white lighted button.

2
Place your glass or bottle under the dispenser tap.



3

Individual water amount:

Select your desired water type icon and hold until preferred water amount has been dispensed.



If the lock button appears red, please press and hold it for 5 seconds to unlock the touch pad. To re-lock, press and hold the lock button for 5 seconds.

Top Compact

